


User Manual Anybus[®] Serial Server

Rev. 1.40:1

HMS Industrial Networks AB


Germany +49 - 721 - 96472 - 0
Japan +81 - 45 - 478 -5340
Sweden +46 - 35 - 17 29 20
U.S.A +1 - 773 - 404 - 3486


ge-sales@hms-networks.com
jp-sales@hms-networks.com
sales@hms-networks.com
us-sales@hms-networks.com



Table of Contents

Preface	About This Document	
	How To Use This Document	P-1
	Important User Information	P-1
	Related Documents.....	P-2
	Document History	P-2
	Conventions & Terminology.....	P-3
	Support	P-3
Chapter 1	About the Anybus Serial Server	
	General.....	1-1
	Mounting	1-2
	Mac ID & Default IP Address.....	1-2
	Connectors	1-3
	<i>Overview</i>	1-3
	<i>I/O & Power Interface</i>	1-4
	<i>ELA-232 Interface</i>	1-4
	<i>Ethernet Interface</i>	1-4
	Indicators.....	1-5
Chapter 2	Configuration	
	IP Address	2-1
	<i>About the Anybus IPconfig Utility</i>	2-1
	<i>Scanning for Connected Devices</i>	2-1
	<i>Changing the IP Settings</i>	2-2
	Installing the Windows Driver (Serial/IP)	2-3
	<i>General Information</i>	2-3
	<i>Log In</i>	2-3
	<i>Welcome Page</i>	2-3
	<i>Network Settings</i>	2-4
	<i>Serial Port Settings (Configuration)</i>	2-5
	<i>Password Settings</i>	2-6
Appendix 3	Technical Specification	

About This Document

How To Use This Document

This document contains a general introduction as well as a description of the technical features provided by the Anybus Serial Server, including the PC-based configuration software.

The reader of this document is expected to be familiar with communication systems in general and the Microsoft Windows operating system.

Important User Information

The data and illustrations found in this document are not binding. We, HMS Industrial Networks AB, reserve the right to modify our products in line with our policy of continuous product development. The information in this document is subject to change without notice and should not be considered as a commitment by HMS Industrial Networks AB. HMS Industrial Networks AB assumes no responsibility for any errors that may appear in this document.

There are many applications of this product. Those responsible for the use of this device must ensure that all the necessary steps have been taken to verify that the application meets all performance and safety requirements including any applicable laws, regulations, codes, and standards.

Anybus® is a registered trademark of HMS Industrial Networks AB. All other trademarks are the property of their respective holders.

The examples and illustrations in this document are included solely for illustrative purposes. Because of the many variables and requirements associated with any particular implementation, HMS Industrial Networks cannot assume responsibility or liability for actual use based on these examples and illustrations.

- | | |
|------------------|---|
| Warning: | This is a class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures. |
| ESD Note: | This product contains ESD (Electrostatic Discharge) sensitive parts that may be damaged if ESD control procedures are not followed. Static control precautions are required when handling the product. Failure to observe this may cause damage to the product. |

Conventions & Terminology

The following conventions are used throughout this document:

- Numbered lists provide sequential steps
- Bulleted lists provide information, not procedural steps
- The term ‘Serial Server’ is refers to the Anybus Serial Server
- EIA-485 is also commonly referred to as RS-485
- EIA-232 is also commonly referred to as RS-232

Support

HMS Sweden (Head Office)

E-mail:	support@hms-networks.com
Phone:	+46 (0) 35 - 17 29 20
Fax:	+46 (0) 35 - 17 29 09
Online:	www.anybus.com

HMS America

E-mail:	us-support@hms-networks.com
Phone:	+1-773-404-2271
Toll Free:	888-8-Anybus
Fax:	+1-773-404-1797
Online:	www.anybus.com

HMS Germany

E-mail:	ge-support@hms-networks.com
Phone:	+49-721-96472-0
Fax:	+49-721-964-7210
Online:	www.anybus.com

HMS Japan


E-mail:	jp-support@hms-networks.com
Phone:	+81-45-478-5340
Fax:	+81-45-476-0315
Online:	www.anybus.com

About the Anybus Serial Server

General

A serial server is a device that forwards data between a serial port and an Ethernet network. It can be used to connect your serial devices to a LAN or Internet without any hardware modifications. Together with a special software driver in a PC, it can be used as a remote serial port.

PC applications designed to access devices on a normal serial port, can access the remote serial server without any software modifications. The LAN/Internet network together with the serial server and driver can be viewed as a long “virtual” serial cable




The Anybus Serial Server connects serial devices to Ethernet networks using the IP protocol family.

Some different types of serial devices supported are listed below:


- Scanners
- Printers
- PLC's
- Data Collection Devices
- Telecommunications Equipment
- Data Display Devices
- Security Alarms and Access Control Devices
- Hand-held Instruments
- Modems

Mounting

A: Snap On



B: Snap Off



Procedure

1. Snap the Serial Server on to the DIN-rail (as described on pictures above).
2. Connect the Ethernet cable to the RJ45 connector.
3. Connect the serial device to the 9-pole DSUB connector.
4. Connect the Power Supply and apply power.
5. Now you can start using the Serial Server.
(use the Anybus IPconfig Utility to configure the IP address and other network settings).

See also...

- 2-1 “IP Address”

Mac ID & Default IP Address

The default IP address of the Serial Server is 10.200.1.X, where X is the last number of the MAC ID (Can be found on the label on the device, displayed in HEX format).




See also...

- 2-1 “IP Address”

Connectors

Overview



#	Description	Comments
1	I/O & Power Interface	See 1-4 "I/O & Power Interface"
2	EIA-232 Interface	See 1-4 "EIA-232 Interface"
3	Ethernet Interface	See 1-4 "Ethernet Interface"

I/O & Power Interface

#	Signal	Comments
24	Vin+	Voltage Range: 9... 32VAC/DC
23	Vin-	(Ground connection)
22	Digital in 1+	-
21	Digital in 2-	
20	Digital Input Common	
19	(not connected)	
18		
17	EIA-232 Receive	(Not used)
16	EIA-232 Transmit	
15	EIA-485 Common	This port can be used to connect to any equipment with an EIA-485 interface.
14	EIA-485 Line A	
13	EIA-485 Line B	

See also...


- 3-1 “Technical Specification” (Power Supply Requirements)

EIA-232 Interface

The 9-pole DSUB, male connector on the Serial Server features a fully equipped EIA-232 interface. This port can be used to connect to any equipment with an EIA-232 interface. The Serial Server is configured as a DTE device.

The following signals are available:


#	Signal	Comments
1	CD	Carrier Detect
2	Rx	Receive
3	Tx	Transmit
4	DTR	DTE Ready
5	GND	Signal ground
6	DSR	DCE Ready
7	RTS	Request To Send
8	CTS	Clear To Send
9	RI	Ring Indicator



Ethernet Interface

The Ethernet interface supports 10/100Mbps, using a standard RJ45 connector.

Indicators



LED	State	Function
Module Status	Off	No power
	Green	Module is running in normal mode
	Orange	During boot-up
Serial Link Status	Green, flashing	Serial Packet receive (on either port)
	Red, flashing	Serial Packet transmit (on either port)
	Orange	During boot-up
LAN Activity	Green, flashing	Ethernet Packet received
	Red, flashing	Ethernet Collision detected
Link 10/100	Off	No Ethernet Link detected
	Green	Ethernet network detected, 10Mbps
	Orange	Ethernet network detected, 100Mbps

Configuration

IP Address

About the Anybus IPconfig Utility

The Anybus IPconfig utility is a PC-based configuration utility used to set TCP/IP network settings in the Serial Server. This utility has the ability to scan the Ethernet network for connected Anybus products and let the user set IP-address, net mask, gateway, DNS and hostname for each device.

Installation

- **System Requirements**
 - 133MHz CPU (or higher)
 - 5Mb of free hard disk space
 - Microsoft Windows 95/98/ME/NT/2000/XP
 - Network Interface (Ethernet)

- **Installation Procedure**


There are two methods to install the Anybus IPconfig utility, either downloading it from the HMS website or use the installation CD ROM.

- Using the CD ROM: Run “Setup-AnybusIPconfig.exe” and follow the on-screen instructions.
- From website: Download the self-extracting installation package “Setup-AnybusIPconfig.exe” from www.anybus.com and run it.

Scanning for Connected Devices

When the Anybus IPconfig utility is started, it will scan the Ethernet network for Anybus products. All detected devices will be presented in a list in the main window. To alter the settings for a device, double click on its' entry in the list.

If you want to force a new scan for devices, you can press the “Scan” button.




Column	Contents	Comments
IP	The IP address	-
SN	The subnet mask	-
GW	The default gateway	-
DHCP	Dynamically assigned IP address On/Off	-
Version	The version of the application-software	-
Type	The product type	-
MAC	The MAC address of the Serial Server	Printed on a label on the device in HEX format

See also...

- 1-2 “Mac ID & Default IP Address”

Changing the IP Settings

To change the IP settings on a detected device, double-click on the device you want to configure in the list of devices. This will open up a dialog where you can enter the desired IP configuration.



Field	Contents
IP Address	The IP address of the Serial Server
Subnet mask	Mask network
Default gateway	The default gateway in the network
Primary DNS	The primary Domain Name Server
Secondary DNS	The primary Secondary Name Server (if it exists)
Hostname	Here you can enter a hostname of your device.
Password	The default password for authentication of the new settings is 'admin'.
New Password	To change the password, first check the 'Change password' checkbox.
DHCP	<p><u>Setting:</u> <u>Meaning:</u></p> <p>On Use server-assigned IP settings.</p> <p>Off Use the settings described below.</p> <p>Note: Do not select the DHCP option unless you have a DHCP server available on the network.</p>
Change Password	Check this checkbox to enable the 'New password'-field

(Pressing 'Set' will cause the Serial Server to reboot and apply the new settings).

To obtain the necessary information about IP address, subnet mask etc. please contact your network administrator.

Note: You can test the new settings by opening a web-browser and enter the IP you just selected. If you selected DHCP and want to know what IP your device have been assigned, you can do a new scan with the Anybus IPconfig utility to view the new network configuration information.

Installing the Windows Driver (Serial/IP)

General Information

To be able to use the Serial Server you need to install the Serial/IP driver on a PC. For installation instructions, consult the “Serial/IP Quick Start” available at the HMS website (www.anybus.com).

Log In

Open a web browser (e.g. Internet Explorer) and enter the IP address you have set on the Serial Server unit with the Anybus IPconfig utility.

Example:

If you entered the address 10.10.10.83 then you should enter the text below in the address field of the browser and press enter:

```
http://10.10.10.83
```


Now you should see the login screen (see figure). To be able to configure the serial server you should enter “admin” in the user name box. The default password is “admin”. You can later change the default password to something else. This will be described later in the section “Admin”.

Note: If you have problems to log in and you are sure that your password is correct, make sure that Caps Lock is not enabled on your keyboard.



Welcome Page

The welcome page of the Serial Server.



Network Settings

If you press the Network link you will be presented with the following view.

The screenshot shows the 'AnyBus Serial Server' web interface. At the top, there are navigation tabs: 'Start', 'Network', 'Configuration', and 'Admin'. The 'Network' tab is active. Below the navigation, there is a 'Network' section with a sub-header 'Network'. Underneath, there are two radio buttons: 'Dynamic IP' (selected) and 'Static IP'. Below these are several input fields: 'Host name' (text input), 'IP Address' (four dropdown menus showing 10, 10, 12, 201), 'Netmask' (four dropdown menus showing 255, 255, 255, 0), 'Gateway' (four dropdown menus showing 10, 10, 12, 254), 'Primary DNS' (four dropdown menus showing 10, 10, 12, 36), and 'Secondary DNS' (four dropdown menus showing 10, 10, 12, 12). At the bottom right of the form is a 'save' button.

On this page you can view and change the TCP/IP network settings in the device. These settings are the same as the ones set by the Anybus IPconfig utility. To obtain the necessary information about IP address, Subnet mask etc. please contact your network administrator.

Field	Details
DHCP	<p>Setting: Meaning:</p> <p>Dynamic IP Use server-assigned IP settings.</p> <p>Static IP Use the settings described below.</p> <p>Note: Do not select 'Dynamic IP' unless you have a DHCP server available on the network.</p>
Host Name	Here you can enter a hostname of your device.
IP Address	The IP address.
Netmask	The subnet mask
Gateway	The default gateway
Primary DNS	The primary Domain Name Server
Secondary DNS	The primary Secondary Name Server (if it exists)

(Press "Save Settings" to update your configuration).

Serial Port Settings (Configuration)

If you press the Configuration link you will be presented with the following view.

The screenshot displays the configuration page for the AnyBus Serial Server, version 1.40.0. The page is divided into two sections for Serial Port EIA-232 and Serial Port EIA-485. Each section contains the following fields:

- Serial Port EIA-232:**
 - Server Port Number: 2000
 - Modbus Mode: On Off
 - Silent Time: ms: 0
 - Manual Serial Settings
 - Baudrate: 300 bps
 - Character Format: 7 data bits, No parity, 1 stop bit
 - Flowcontrol: NONE
 - Modem control lines: On
- Serial Port EIA-485:**
 - Server Port Number: 2001
 - Modbus Mode: On Off
 - Silent Time: ms: 0
 - Manual Serial Settings
 - Baudrate: 300 bps
 - Character Format: 7 data bits, No parity, 1 stop bit

A 'save' button is located at the bottom right of the configuration area.

The page is divided in two sections, one for each serial port. All fields exist for both ports except that the EIA-485 port has no flow control selection.

Field	Description
Serial Port Number	The Serial Server answers on incoming connections on this IP port number. The defaults are 2000 for EIA-232 port and 2001 for EIA-485 port. Use these numbers when you connect from the Serial/IP driver, telnet or other application that can connect to a socket port. For example, if you connect to IP port 2000 your communication will go through the EIA-232 serial port.
Modbus Mode	This is regarding fragmentation on received messages on the serial port. If On, it makes the low level serial driver to wait 3.5 characters (standard Modbus message break time) before it passes the received characters further. Then it may be sent in one TCP/IP packet to prevent fragmentation on the receive side. The 3.5 char time is calculated from the current baud rate. If Off, you still can select the time in milliseconds (see below).
Silent Time	Number of milliseconds to wait in silence before the received characters is passed to the serial server application in the Serial Server. A value of 0 disables this feature. If so, characters received in about 10 milliseconds will be sent in each TCP/IP packet. This may mean less delay for each received byte, but may mean more TCP/IP overhead and maybe fragmentation of the serial packet.
Manual Serial Settings	If you want to lock the settings on the serial port, check this box. This is useful for various reasons. For example, if you connect with some application that doesn't do the remote serial port setup. Normally your PC serial application does this through the Serial/IP driver when you connect to a Serial/IP driver Com port. If you use a program that doesn't set up the remote serial port, the Serial Server defaults to: 19200 baud rate, 8 data bits, No parity, 1 stop bit.
Baudrate ^a	Sets the communication rate on the serial port. Valid settings are 300, 600, 1200, 2400, 4800, 9600, 19200, 38400, 57600 and 115200.
Character Format ^a	First field is how many bits are used for each character. You can set 7 or 8 data bits. Second field is for parity configuration. Choose between No, Even or Odd parity. The third field is for how many stop bits to use. There can be 1 or 2.

Field	Description
Flow Control ^a	For the EIA-232 port you can select if you want flow control handled by the UART. If this is selected then transmit is automatically stopped/continued when serial buffer is full/available. You can choose between NONE, CTS/RTS and XON/XOFF. NONE disables UART flow control. If CTS/RTS is selected the two UARTs involved uses two dedicated wires in the serial cable to control flow. The Serial Server uses RTS when it wants to transmit and gets CTS back when it is clear to send. Be sure to use a serial cable with these wires connected. If XON/XOFF is used the remote UART should send characters to signal its buffer state.
Modem Control Lines ^a	If this option is set to 'On', the modem control lines will be taken in account (DCD, DTR). If set to 'Off', the modem control line states will be ignored.

a. This setting is available only if the 'Manual Serial Settings'-checkbox has been checked.

Press "Save" to update your configuration. You will be asked to press a reboot button in the next view. After about 20 seconds has passed you can press the start menu field up in the right corner to take you back to the start page.

Note: The Server Port Number must match the value entered in the Serial/IP Driver.

Password Settings

If you press the Admin link you will be presented with the following view.

The screenshot shows the web interface for the AnyBus Serial Server. At the top, there is a header with the 'AnyBus Serial Server' logo on the left and 'SerialServer' on the right, with a version number 'ver.: 1.40.0' in the top right corner. Below the header is a navigation menu with 'Start', 'Network', 'Configuration', and 'Admin' links. The main content area is titled 'Set Password' and contains three input fields: 'Login' (with 'admin' entered), 'Password', and 'Confirm Password'. A 'save' button is located at the bottom right of the form.

This screen allows you to change the administrator password for this device. Enter the new password in the Password box and in the Confirm Password box. Click "Save Password" to change the password.

Technical Specification

Ethernet Interface

- 10Base-T or 100Base-TX (IEEE 802.3)
- RJ45 Connector

Serial Interface (EIA-232)

- EIA-232 with full modem control (RTS,CTS,DCD,DTR,DSR,RI)
- 300... 115.200bps operation
- 9-pole DSUB connector

Power Supply Requirements

- 9... 32 VAC/DC
- 1.7W

Temperature Range

- 0... 55 °C (Operating)
- -25... 75 °C (Non-operating)

Humidity

- 5... 93% RH, non-condensing

Housing Material

- Grey plastic (LEXAN 940)
- Self-extinguishing according to UL94-V0

Mounting Option

- DIN-rail (EN50022)

CE Certification

- According to EN 50 081-2:1993 and EN 61000-6-2:1999

